


Full instructions and video tuto.

https://www.smart-impulse.com/en/techdoc/



Help Desk

+44 (0) 330 684 6080

SETUP

When the 3G coverage is not sufficient in the analysed switchrooms (ex: basement), the 3G extension kit enables to move the 3G antenna to a zone with a higher coverage. (ex: ground floor).

To install it:

- Plug in the Smart Router delivered with the Smart X® ("Smart Router" label) close to the Smart X installed.
- Plug in the 3G Extension Kit ("3G Extension Kit" label) in the nearest area with sufficient 3G coverage, then insert the 3G USB-drive.
- Connect the 2 routers with the Ethernet cable (length 30 metres).

After 2 minutes, the Smart X units pair automatically to the Smart Router and can communicate with the Smart Impulse server (▼ icon on the Smart X screen).

